

click to view the bag on our website!

Classic: 10mm padding  
Superior: 25mm padding

KEYBOARD					
Manufacturer	Model	Keys	Dimensions (cm)		
			Width	Depth	Height
Casio	CDP-100	88	132.2	27.8	13.2
Casio	CDP-120	88	132.2	28.6	12.9
Casio	CDP-200	88	133.3	27.8	13.3
Casio	CDP-220	88	132.2	28.6	12.9
Casio	CTK-1100	61	94.9	30.4	9.3
Casio	CTK-2200	61	94.6	30.7	9.2
Casio	CTK-3000	61	94.9	35.4	11.2
Casio	CTK-3200	61	94.5	34	12
Casio	CTK-4000	61	95	37.6	13
Casio	CTK-4200	61	94.8	35	10.3
Casio	CTK-5000	61	95	37.6	13
Casio	CTK-6000	61	94.5	37.8	13.2
Casio	CTK-6200	61	94.5	37.8	13.2
Casio	CTK-7000	61	94.5	37.8	13.2
Casio	CTK-7200	61	94.5	37.8	13.2
Casio	LK-240	61	94.6	30.7	9.2
Casio	PX-130	88	132.2	28.6	13.5
Casio	PX-130	88	132.2	28.6	13.5
Casio	PX-135	88	132.2	28.6	13.5
Casio	PX-150	88	132.2	28.6	13.5
Casio	PX-330	88	132.2	28.6	13.5
Casio	PX-350	88	132.2	28.6	13.5
Casio	PX-3BK	88	132.2	28.6	13.5
Casio	PX-5BK	88	132.2	28.6	13.5
Casio	WK-6500	76	118.7	39.9	14.9

GIG BAG				
Gig bag	Style	Inner dimensions (cm)		
		Width	Depth	Height
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16

Keyboard bag sizing chart

**Please note:** padded gig bags are not as strong as hard shell flight cases - they are a convenient lightweight alternative and are suitable for most keyboards up to a weight of about 15kg, after which a full flight case is probably more appropriate.

**The UK's most popular gig bags**

Our gig bags combine instrument protection and affordability in a range of exciting colours and designs and are intended to fit a variety of keyboard models from different manufacturers.

Carrying comfort is guaranteed thanks to the integrated backpack straps and GripEZE handle. A full length zip up pocket across the top of the bag allows storage of music,

instructions and other accessories. On the outside of the bag there is an external anti scuff rubber pad to prevent damage to the bag itself.

Tom and Will gig bags have strong YKK zippers that open around the top of the bag, making it quick and easy to put your instrument away.



KEYBOARD					
Manufacturer	Model	Keys	Dimensions (cm)		
			Width	Depth	Height
Casio	WK-7500	76	118.7	39.9	14.9
Casio	WK-7600	76	118.7	39.9	14.9
Korg	PA3X	61	119.2	36.6	14.5
Korg	SP-170	88	131.2	32.5	13.3
Korg	SP-170S	88	131.2	32.5	13.3
Korg	SP-250	88	129.5	38	14
Korg	SP-280	88	136	40.6	14
Kurzweil	SP2X	76	142	30	12
Roland	AX-09	49	83.2	24.5	9.5
Roland	AX-Synth	49	114.2	26.6	8.7
Roland	BK-5	61	104.4	31.7	12.9
Roland	E-09	61	104.5	32	12.8
Roland	E-50	61	102	35.6	12.7
Roland	FantomG6	61	106.6	41.1	14.2
Roland	FantomG7	88	127.8	41.1	14.2
Roland	FP-4F	88	134.2	30.5	13.5
Roland	FP-50	88	134.2	30.5	13.5
Roland	FP-7F	88	134.6	36.9	13.7
Roland	FP80	88	134.6	36.9	13.7
Roland	Gaia SH-01	49	68.9	31.7	10
Roland	GW-8L	61	104.5	31.8	12.2
Roland	JUNO-Di	61	100.8	30	10.5
Roland	JUNO-Gi	61	100.8	30	10.5
Roland	JUNO-STAGE	76	125.1	34.4	11.2



GIG BAG				
Gig bag	Style	Inner dimensions (cm)		
		Width	Depth	Height
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
85KB60	Superior	135	40	17
85KB60	Superior	135	40	17
85KB65	Superior	148	40	17
85KB20	Superior	95	38	13
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
85KB60	Superior	135	40	17
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
85KB20	Superior	95	38	13
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17

Keyboard bag sizing chart

**Please note:** padded gig bags are not as strong as hard shell flight cases - they are a convenient lightweight alternative and are suitable for most keyboards up to a weight of about 15kg, after which a full flight case is probably more appropriate.

KEYBOARD					
Manufacturer	Model	Keys	Dimensions (cm)		
			Width	Depth	Height
Roland	Prelude	61	104.4	31.7	12.1
Roland	RD-300NX	88	141	34	14
Roland	RD-700NX	88	141.4	37.5	14.8
Roland	V-Synth GT	88	106.6	41.1	12.5
Roland	VP-770	76	88.6	36.9	11.8
Yamaha	CP-1	88	138.1	40.5	17.4
Yamaha	CP-5	88	138.1	40.5	17.4
Yamaha	CP-50	88	138.1	33.2	16.5
Yamaha	CP33	88	131.2	33	15.1
Yamaha	CP33	88	131.2	33	15.1
Yamaha	CP4	88	133	35.2	13.2
Yamaha	CP40	88	133.2	35.2	16.3
Yamaha	DGX230	76	117.8	41.2	13.7
Yamaha	EZ200	61	94.5	34.8	11.8
Yamaha	MM6	61	94.8	37.4	12.2
Yamaha	MOTIFXF6	61	104.5	39.1	12.2
Yamaha	MOTIFXF7	76	125.2	39.1	12.2
Yamaha	MOTIFXS6	61	104.5	39.1	12.2
Yamaha	MOTIFXS7	76	125.2	39.1	12.2
Yamaha	MoX6	61	103.5	35.8	12.5
Yamaha	MoX8	88	132.2	40.5	16.8
Yamaha	MoXF6	61	104	35.8	12.5
Yamaha	MoXF8	88	132.2	40.5	16.8
Yamaha	NP11	61	103.6	25.9	10.5
Yamaha	NP30	76	124.4	25.9	10
Yamaha	NP31	76	124.4	25.9	10
Yamaha	NPV60	76	122.8	31.2	11.1
Yamaha	NPV80	76	122.8	31.2	11.1



GIG BAG				
Gig bag	Style	Inner dimensions (cm)		
		Width	Depth	Height
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
85KB65	Superior	148	40	17
85KB65	Superior	148	40	17
85KB60	Superior	135	40	17
85KB20	Superior	95	38	13
85KB65	Superior	148	40	17
85KB65	Superior	148	40	17
85KB65	Superior	148	40	17
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
85KB60	Superior	135	40	17
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
85KB60	Superior	135	40	17
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
85KB60	Superior	135	40	17
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
85KB60	Superior	135	40	17
81KB35	Classic	107	33	13
85KB35	Superior	107	33	13
81KB45	Classic	126	28	12
85KB45	Superior	126	28	12
81KB45	Classic	126	28	12
85KB45	Superior	126	28	12
81KB45	Classic	126	28	12
85KB45	Superior	126	28	12
81KB45	Classic	126	28	12
85KB45	Superior	126	28	12

Keyboard bag sizing chart

**Please note:** padded gig bags are not as strong as hard shell flight cases - they are a convenient lightweight alternative and are suitable for most keyboards up to a weight of about 15kg, after which a full flight case is probably more appropriate.

KEYBOARD					
Manufacturer	Model	Keys	Dimensions (cm)		
			Width	Depth	Height
Yamaha	P-155	88	133.4	35.1	14
Yamaha	PSR-A2000	61	100.3	43.3	14.8
Yamaha	PSR-E233	61	94.5	34.8	11.8
Yamaha	PSR-E243	61	94.5	34.8	11.8
Yamaha	PSR-E333	61	94.5	36.9	11.8
Yamaha	PSR-E343	61	94.5	36.9	11.8
Yamaha	PSR-E423	61	94.6	40.2	13.6
Yamaha	PSR-E433	61	94.6	40.2	14
Yamaha	PSR-S550	61	94.6	40.2	13
Yamaha	PSR-S650	61	94.6	40.5	13.7
Yamaha	PSR-S710	61	100.3	43.3	14.8
Yamaha	PSR-S750	61	100.3	43.3	14.8
Yamaha	PSR-S910	61	100.3	43.3	14.8
Yamaha	PSR-S950	61	100.3	43.3	14.8
Yamaha	Tyros3	61	114	45	14.3
Yamaha	Tyros4	61	114	45	14.3
Yamaha	Tyros5-61	61	114	45	14.3
Yamaha	YPT220	61	94.5	34.8	11.8
Yamaha	P-105	88	132.6	29.5	16.3
Yamaha	P-35	88	132.6	29.5	15.4
Yamaha	P-85	88	132.6	29.5	15.1
Yamaha	P-95	88	132.6	29.5	15.1
Yamaha	YPT210	61	94.5	34.8	11



GIG BAG				
Gig bag	Style	Inner dimensions (cm)		
		Width	Depth	Height
81KB55	Classic	135	35	17
85KB55	Superior	135	35	17
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
85KB20	Superior	95	38	13
81KB25	Classic	97	42	16
85KB25	Superior	97	42	16
81KB25	Classic	97	42	16
85KB25	Superior	97	42	16
81KB25	Classic	97	42	16
85KB25	Superior	97	42	16
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
81KB30	Classic	102	45	16
85KB30	Superior	102	45	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
81KB40	Classic	118	47	16
85KB40	Superior	118	47	16
85KB20	Superior	95	38	13
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
81KB50	Classic	135	30	16
85KB50	Superior	135	30	16
85KB20	Superior	95	38	13

Keyboard bag sizing chart

**Please note:** padded gig bags are not as strong as hard shell flight cases - they are a convenient lightweight alternative and are suitable for most keyboards up to a weight of about 15kg, after which a full flight case is probably more appropriate.